

## MOTION-SENSING TRAILER TRACKER

Instantly detect trailer theft or departures/arrivals with our 8-Year Motion-Sensing Wireless Tracker! Get immediate alerts when your trailer moves and monitor its location with pinpoint GPS accuracy.

**PERFECT FOR:** Trailer owners, fleet managers, equipment rentals, and construction companies

**KEY BENEFITS:** 8-year battery life, theft detection alerts, geofence capabilities, weatherproof design.

## Motion-Sensing Trailer Tracker

### 8-Year Battery Life | Wireless Installation

Our weather-proof tracker installs instantly and securely with magnets or screws. Due to its small size and low profile, it is easy to hide from thieves. It is waterproof and can handle excessive heat or cold, so it will continue to work in extreme weather conditions.

Other trackers only report where your trailer is once or twice a day at scheduled times, so they can only send theft alerts at those times. But our tracker has innovative motion detection that immediately alerts you of a potential theft, rather than many hours later at a scheduled report time. Unlike other wireless trackers that can't be used to track deliveries, ours can notify of daily departures and arrivals and still last for 4-5 years.

Your battery will last for 8 years with 2 location updates (pings) per day. Battery life will vary when you change the number of pings per day (will last 4 years with 4 pings per day).



### Motion-Sensing Trailer Tracking Specification Highlights

Pinpoint GPS Tracking	Geo-Fence Alerts
4G Backup Locating	Weather Proof (IP67)
8-Year Battery Life	4G LTE Connectivity
Concealable Design	Magnetic Installation

## Key Benefits & Features

### Detect Theft with Instant Alerts

Receive immediate text/email alerts when your trailer is moved without authorization, allowing for quick response and recovery.

### 8-Year / 5000+ Ping Batter

Long-lasting battery eliminates frequent replacement needs. Get up to 8 years with 2 daily updates or 4 years with 4 updates per day.

### Always Get Location Info

Uses cell towers to estimate location when GPS satellites are unavailable, ensuring you always know where your assets are.

### Motion Detection Benefits

Updates as frequently as every 7 minutes when in motion. Know within minutes if a parked trailer starts or stops moving.

### Geo-fence Alerts

Set boundaries around locations and receive alerts when your trailer enters or exits your yard, job-site, or even specific regions.

### Geo-fence Alerts

Set boundaries around locations and receive alerts when your trailer enters or exits your yard, job-site, or even specific regions.

### Trailer Owners Use Our Trackers For:

Immediate theft alerts

No subscription costs

Instant notifications of trailer departures and arrivals

Monitor unauthorized trailer moves

Monitoring current location and history

Monitor speed and direction



**Pinpoint GPS Tracking**



**4G Backup Locating**




**8 Year Battery Life**



**Concealable**



**Geo-Fence Alert**



**Weather Proof**

# Quick Start Guide

## STEP 1 Activation and Login Information

Have the 15 digit IMEI # (see label on the bottom of your tracker) handy during the activation process.

If your device was not activated upon purchase, please visit: <https://matrackinc.com/reseller/client/gps-activation/> to fill out and submit the activation form.

After activation, your login information will be emailed to you. Use the username and password in that email to access your account at: [matrack.io](https://matrack.io). Once logged into your account, you can begin using your tracker.



## STEP 2 Finding the Ideal Placement for Your Tracker

1. Your tracker can receive signals through any non-metallic material, so first be sure not to place it where it's fully enclosed by metal on all sides.
2. Your tracker can be placed inside plastic enclosures, under a trailer chassis, etc., and function normally.
3. As a general rule, the more open air the tracker is exposed to, the better the signal quality that it receives. So, be sure to test the tracker's signal reception, if you install it where it has little exposure to open air (see Step 4 to test placement)
4. When the tracker cannot detect enough satellite signals for a GPS location-fix, it will default to reporting the location of the nearest cell tower instead. If you notice these cell tower back-up locations occurring frequently on your tracking reports, you may wish to reposition the tracker for better satellite signal reception.

## STEP 3 Optional: Find the rectangular glass window on the side of the device and identify the LED lights

**Blue:** Cellular LED

**Green:** GPS LED



**STEP 4****Optional: Prompt the Device to Report Its Location**

Find the "Test" button next to the LED light. To instantly pinpoint your location, hold down the button until the LED lights flash Green and Blue.

As the device connects to the GPS & cellular networks, the Green GPS LED light blinks first, followed by the Blue cellular LED light.

The Green GPS LED light will then blink more slowly and turn off within a few minutes.

When both lights are off, this indicates that the device has pinpointed its location and relayed that data to Matrack. You will then immediately see your location appear on the app and user platform as your tracker's most recent update.

Your tracker will still update on its programmed daily schedule, even if you don't do Step 4 and prompt an immediate update from your device

To check the placement of the device, quickly place the tracker in the desired installation location as soon as the LEDs start flashing in Step 4. Then check your account to confirm a successful location report.

**For technical assistance, please call: 855-OK-TRACK (855-658-7225) 24/7**  
**For 24/7 support by email, please message us at: [support.gps@matrackinc.com](mailto:support.gps@matrackinc.com)**

## **Ready to secure your trailers?**

Get started today with industry-leading tracking solutions  
designed specifically for trailers and transport assets

**Request a Quote: 855-658-7225**